



# St. John's, NL

## Terminal spec sheet



	Bay 1	Bay 2	Bay 3	Bay 4
<b>Loading – Truck Rack</b>	<b>Bottom</b>	<b>Bottom</b>	<b>Bottom</b>	<b>Bottom</b>
Gasoline (Regular)	✓	✓✓	✓✓	
Gasoline (Premium)	✓		✓	
Ultra Low Sulphur Diesel (Clear & Dyed)		✓	✓	✓
Heating Oil (Clear & Dyed)	✓	✓		✓✓
Marine Gas Oil (Clear & Dyed)	✓			✓
	<b>Pier 23</b>		<b>Pier 24</b>	
<b>Docks – Pipe</b>				
Marine Gas Oil (Clear)		✓		✓

✓✓ signifies that Bay has two arms (speed loading) for that product.

**Address:**  
Pier 24 South Side Rd.  
St. John's, NL  
A1E 6E3

**Hours of operation:**  
24/7, 365 days a year

**Phone:** 709.758.3003  
**Fax:** 709.758.3092

Call our Customer Support Team at 1.866.865.8800 or email us at [IOCCustomerSupport@irvingoil.com](mailto:IOCCustomerSupport@irvingoil.com)



# St. John's, NL

## Terminal spec sheet

### Driver orientation training

To ensure all lifts are made easily and safely, we offer training for drivers. Here are the steps to take to attend our training:

#### STEP 1 – Complete our compliance checklist

Please ensure you have the following documents before your orientation training. Each of these documents must be with you during every visit to our terminal.

##### Carrier requirements:

Terminal access agreement

##### Trailer requirements:

- Annual Inspection Certificate (B620)
- Five year Inspection Certificate (B620)
- Annual Probe Inspection Certificate

##### Driver requirements:

- TDG
- WHMIS
- Valid driver's licence
- CPPI

Outermost layer of clothing must be fire retardant, high-visibility, Class III (red, orange or yellow-green) as per CSA Standard Z96-15 High Visibility Safety Apparel.

#### STEP 2 – Schedule an appointment

To schedule your driver orientation training, please call the St. John's terminal (709.758.3003) more than 24 hours in advance. Conducted between 8:00 am and 5:00 pm, Monday to Friday.

#### STEP 3 – Attend the training

- The driver orientation training takes about one to two hours.
- Training includes an orientation video, review of standards and procedures, site orientation, supervised loads, and compliance checklist.
- To facilitate orientation, a certified driver is required to accompany your new driver.
- Drivers must have ten supervised loads and meet our compliance checklist prior to receiving their access card.
- Completion of orientation is required annually.



If you have any questions, please contact our Customer Support Team at **1.866.865.8800** or by email at [IOCCustomerSupport@irvingoil.com](mailto:IOCCustomerSupport@irvingoil.com).

Thanks for your business, and we look forward to serving you.